



Prepare to Test under Closed House Conditions:

It is very important to maintain “closed house conditions” for twelve hours before you start the test and during the entire testing because ventilation can increase or decrease radon levels in unpredictable ways. **Keep all windows and doors closed except for normal entry and exit.**

Run Heating/Central Air Systems normally. Operate Air Conditioners (window units) in re-circulation or vent closed mode. DO NOT use attic and window fans, fireplaces and wood stoves (unless they are the primary heat source) for the duration of test.

TEST RESULTS WILL BE INVALID IF CLOSED HOUSE CONDITIONS ARE NOT MAINTAINED.